



- S801 HI BLEND SWITCH: OFF
- S802 MONO SWITCH: STEREO
- S803 FM: ON
- S804 AM: OFF
- S805 POWER SWITCH: OFF